

FBX Adapter Specifications

FBX Adapter Model	5.0 Volt PCI Support	3.3 Volt PCI Support	Type of Fax Lines Supported	Locally Connected Fax Machines Supported	Fax Archiving	IntraFAX Gateway	IntraFAX Client	DTMF to Inbound Routing	PSTN Fax to Folder	PSTN FAX to Email
NDIFBX3D	✓		3 DID				✓	✓		
NDIFBX3D-A	✓		3 DID		✓		✓	✓		
NDIFBX3D-A-I	✓		3 DID		✓	✓		✓		
NDIFBX3D-I	✓		3 DID			✓		✓		
NDIFBX3DX		✓	3 DID				✓	✓		
NDIFBX3DX-A		✓	3 DID		✓		✓	✓		
NDIFBX3DX-A-I		✓	3 DID		✓	✓		✓		
NDIFBX3DX-I		✓	3 DID			✓		✓		
NDIFBX3L	✓		0 or 1 PSTN*	3 or 2 LocalFAX*			✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3L-A	✓		0 or 1 PSTN*	3 or 2 LocalFAX*	✓		✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3L-A-I	✓		0 or 1 PSTN*	3 or 2 LocalFAX*	✓	✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3L-I	✓		0 or 1 PSTN*	3 or 2 LocalFAX*		✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3LX		✓	0 or 1 PSTN*	3 or 2 LocalFAX*			✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3LX-A		✓	0 or 1 PSTN*	3 or 2 LocalFAX*	✓		✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3LX-A-I		✓	0 or 1 PSTN*	3 or 2 LocalFAX*	✓	✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3LX-I		✓	0 or 1 PSTN*	3 or 2 LocalFAX*		✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX3P	✓		3 PSTN				✓	✓	✓	✓
NDIFBX3P-A	✓		3 PSTN		✓		✓	✓	✓	✓
NDIFBX3P-A-I	✓		3 PSTN		✓	✓		✓	✓	✓
NDIFBX3P-I	✓		3 PSTN			✓		✓	✓	✓
NDIFBX3PX		✓	3 PSTN				✓	✓	✓	✓
NDIFBX3PX-A		✓	3 PSTN		✓		✓	✓	✓	✓
NDIFBX3PX-A-I		✓	3 PSTN		✓	✓		✓	✓	✓
NDIFBX3PX-I		✓	3 PSTN			✓		✓	✓	✓
NDIFBX6D	✓		6 DID				✓	✓		
NDIFBX6D-A	✓		6 DID		✓		✓	✓		
NDIFBX6D-A-I	✓		6 DID		✓	✓		✓		
NDIFBX6D-I	✓		6 DID			✓		✓		
NDIFBX6DX		✓	6 DID				✓	✓		
NDIFBX6DX-A		✓	6 DID		✓		✓	✓		
NDIFBX6DX-A-I		✓	6 DID		✓	✓		✓		
NDIFBX6DX-I		✓	6 DID			✓		✓		
NDIFBX6L	✓		0 or 1 PSTN*	6 or 5 LocalFAX*			✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6L-A	✓		0 or 1 PSTN*	6 or 5 LocalFAX*	✓		✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6L-A-I	✓		0 or 1 PSTN*	6 or 5 LocalFAX*	✓	✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6L-I	✓		0 or 1 PSTN*	6 or 5 LocalFAX*		✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6LX		✓	0 or 1 PSTN*	6 or 5 LocalFAX*			✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6LX-A		✓	0 or 1 PSTN*	6 or 5 LocalFAX*	✓		✓	✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6LX-A-I		✓	0 or 1 PSTN*	6 or 5 LocalFAX*	✓	✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6LX-I		✓	0 or 1 PSTN*	6 or 5 LocalFAX*		✓		✓	✓ (1 Port)*	✓ (1 Port)*
NDIFBX6P	✓		6				✓	✓	✓	✓
NDIFBX6P-A	✓		6		✓		✓	✓	✓	✓
NDIFBX6P-A-I	✓		6		✓	✓		✓	✓	✓
NDIFBX6P-I	✓		6			✓		✓	✓	✓
NDIFBX6PX		✓	6				✓	✓	✓	✓
NDIFBX6PX-A		✓	6		✓		✓	✓	✓	✓
NDIFBX6PX-A-I		✓	6		✓	✓		✓	✓	✓
NDIFBX6PX-I		✓	6			✓		✓	✓	✓
Note: *	Port 1 on a 3 Port LocalFAX FBX Adapter can be configured as PSTN or LocalFAX. If the first Ports is configured as PSTN, then only 2 LocalFAX Ports will be available.									
Note: *	Port 1 on a 6 Port LocalFAX FBX Adapter can be configured as PSTN or LocalFAX. If the first Ports is configured as PSTN, then only 2 LocalFAX Ports will be available.									
Note: *	Only 1 PSTN Port on a 3 or 6 Port LocalFAX FBX Adapter can be configured as PSTN.									

FBX Adapter Specifications

FBX Adapter Model	PSTN Fax to LocalFAX	LocalFAX to Email	Scan to Email	LocalFAX to PSTN	Customizable LocalFAX Parser	Desktop Faxing	PDF or TIFF Conversion	Detailed Transaction Log	Admin WEB Monitoring Interface
NDIFBX3D							✓	✓	✓
NDIFBX3D-A							✓	✓	✓
NDIFBX3D-A-I							✓	✓	✓
NDIFBX3D-I							✓	✓	✓
NDIFBX3DX							✓	✓	✓
NDIFBX3DX-A							✓	✓	✓
NDIFBX3DX-A-I							✓	✓	✓
NDIFBX3DX-I							✓	✓	✓
NDIFBX3L	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3L-A	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3L-A-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3L-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3LX	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3LX-A	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3LX-A-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3LX-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX3P	✓				✓	✓	✓	✓	✓
NDIFBX3P-A	✓				✓	✓	✓	✓	✓
NDIFBX3P-A-I	✓				✓	✓	✓	✓	✓
NDIFBX3P-I	✓				✓	✓	✓	✓	✓
NDIFBX3PX	✓				✓	✓	✓	✓	✓
NDIFBX3PX-A	✓				✓	✓	✓	✓	✓
NDIFBX3PX-A-I	✓				✓	✓	✓	✓	✓
NDIFBX3PX-I	✓				✓	✓	✓	✓	✓
NDIFBX6D							✓	✓	✓
NDIFBX6D-A							✓	✓	✓
NDIFBX6D-A-I							✓	✓	✓
NDIFBX6D-I							✓	✓	✓
NDIFBX6DX							✓	✓	✓
NDIFBX6DX-A							✓	✓	✓
NDIFBX6DX-A-I							✓	✓	✓
NDIFBX6DX-I							✓	✓	✓
NDIFBX6L	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6L-A	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6L-A-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6L-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6LX	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6LX-A	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6LX-A-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6LX-I	✓ (1 Port)*	✓	✓	✓	✓	✓	✓	✓	✓
NDIFBX6P	✓				✓	✓	✓	✓	✓
NDIFBX6P-A	✓				✓	✓	✓	✓	✓
NDIFBX6P-A-I	✓				✓	✓	✓	✓	✓
NDIFBX6P-I	✓				✓	✓	✓	✓	✓
NDIFBX6PX	✓				✓	✓	✓	✓	✓
NDIFBX6PX-A	✓				✓	✓	✓	✓	✓
NDIFBX6PX-A-I	✓				✓	✓	✓	✓	✓
NDIFBX6PX-I	✓				✓	✓	✓	✓	✓
Note: *	Port 1 on a 3 Port LocalFAX FBX Adapter can be configured as PSTN or LocalFAX. If the first Ports is configured as PSTN, then only 2 LocalFAX Ports will be available.								
Note: *	Port 1 on a 6 Port LocalFAX FBX Adapter can be configured as PSTN or LocalFAX. If the first Ports is configured as PSTN, then only 2 LocalFAX Ports will be available.								
Note: *	Only 1 PSTN Port on a 3 or 6 Port LocalFAX FBX Adapter can be configured as PSTN.								